


AMBYENTA




...kroz život zajedno...












www.ambyenta.com

UPUTSTVO ZA MONTAŽU



Kuhinjski element " LEGO 1 - " G30 "



1  Bočica ljepila 1 kom	2  Drvena tipla 20 kom	3  Baglama ravna 2 kom	4  Podloška bagl. 2 kom	5  Vijak 4x16 8 kom	6  Vijak 4x30 4 kom	7  Ručkica 1 kom	8  Vijak M4x20 2 kom
9  Nosач polica 8 kom	10  Ekseri za leđa 18 kom	11  Nosач visećeg elem. 1 par					

